



$Gen\text{-}Sep^{\scriptscriptstyle\mathsf{TM}}$

A Gen-Sep gas and water separator is a new and valuable tool to protect your set and quiet generator operation.

Gen-Sep will remove nearly all of the cooling water from the exhaust. That water can be drained to a hull fitting just below the waterline. This eliminates the irritating noise created by splashing and pulsating water flow at the exhaust outlet.

Several sizes of Gen-Seps are available. Follow installation instructions supplied with the unit. A basic installation diagram is shown here.







Mfg. by: Alaska Diesel Electric, Inc. Seattle, WA 98107 Tel: (206) 789-3880 • FAX (206) 782-5455 http://www.northern-lights.com All rights reserved. Litho USA L192 10/04 Dealer: